Renault 2.0 Turbo



The product described in the guidance was developed, manufactured and controlled considering the necessary safety reguirements.

The product must be installed properly to ensure a proper function and avoid danger for persons and things.

Please read this installationguide inclusive safety instructions carefully.

Scope of supply:

Quantity	article	
1x	Tuningbox	
1x	Loom	
1x	Bridge plug	
1x	Fastening kit	



- 1. Open the hood.
- 2.Turn the ignition off!
- 3. Remove the ignitionkey!
- 4. Close and lock all doors!
- 5.Do not open any doors while installing the tuningkit!
- 6. Wait 5 minutes before beginning the installation








In order to avoid damages at electronic vehicle components, you have to be sure that you have done all necessary methods for **electostatic discharge** .

Install the electronic in an **waterproof** and **vibrationless** place. Do not make any changes at the tuning-kit!

Do not expand or shorten the loom.

Renault 2.0 Turbo





Overview:

The tuningkit has to be attached to the following points:

- Boost pressure sensor
- Inlet manifold sensor

Required tools:

none

Vorbereitung:

- Move the individual strands of the loom to the associated plug connectors
- Put the required tools by your side (if needed)
- Take the fastening material at your side
- To get the maximum power enhancement, you have to use "super plus" (98 ROZ)


Renault 2.0 Turbo





1. Preperation

- ♦ Before you can start installing the kit, you have to remove the engine cover.
- ♦ The engine cover is only cliped




2. Inlet Manifold Sensor

- Disconnect the plug from the the inlet manifold sensor
- ♦ Attach the inlet manifold plug to the new loom
- ♦ Connect the plug of the new loom the inlet manifold sensor


Renault 2.0 Turbo





3. Boost Pressure Sensor

- Disconnect the plug from the boost pressure sensor
- ♦ Attach the boost pressure plug to the new loom
- Oconnect the plug of the new loom the boost pressure sensor



4. Tuningbox

- ♦ Finally install the cable towards a suitable position
- ♦ The plugs must be engage, so that a safe connection is ensured
- ♦ Fix the cable with cable ties
- ♦ Connect the tuningbox to the new loom